


C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.1/16




FOR C007J/C007JD/C858J/C858JD

★ 适用于UTP/CR/CX, UTQ/CR/CX, UTR/CR/CX, UTS/CR/CX车型

10/07/01


C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.10/16

A
B
C
D
E




TXXXXX

C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.11/16



C007JD PARTS LIST FOR UTQ-J GROUP P.12/16


FOR LEFT SIDE




C007JD PARTS LIST

FOR UTP-J GROUP


P.13/16




C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.14/16




C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.15/16




C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.16/16




C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.2/16




C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.3/16




C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.4/16




C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.5/16



C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.6/16



C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.7/16




FOR C007JD/C858JD


FOR H牌馬達 (HVP-70)
FOR P牌馬達

10/07/01


C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.8/16



C007JD PARTS LIST FOR UTP-J(UTQ-J) GROUP P.9/16



C007J PARTS LIST FOR UTR-J(UTS-J) GROUP P.1/8




FOR C007J/C007JD/ C858J/C858JD

★ 适用于UTP/CR/CX, UTQ/CR/CX, UTR/CR/CX, UTS/CR/CX车型

10/07/01

C007J PARTS LIST FOR UTR-J(UTS-J) GROUP P.2/8



FOR C007J/C007JD/C858J/C858JD

FOR H牌馬達
 FOR P牌馬達


10/07/01

C007J PARTS LIST FOR UTR-J(UTS-J) GROUP P.3/8


FOR UTR/WP/UTU

FOR UTS/UTY

A




UT218J




UT226D
UT226P
WP22(WP)

TO WIPER

UT763



UT534



TO UNDER TRIMMER

B

UT103E
UT103P

TO SYNCHRONIZER

TO SAFETY S.W


EP107

C

TO MAIN POWER

TO PRESSER FOOT

TXXXXX




T999


D

E

UT230-E
FOR CL USE



UT810-A
UT810P-A



FOR C007J/C858J

FOR H牌馬達
FOR P牌馬達

10/07/01

C007J PARTS LIST FOR UTR-J(UTS-J) GROUP P.4/8


A

B


C

D

E



C007J PARTS LIST FOR UTR-J(UTS-J) GROUP P.5/8



C007J PARTS LIST FOR UTK-J(UTS-J) GROUP P.6/8


A

B

C


D

E



UTK/UTS系列

UT218J-A1



C007J PARTS LIST

FOR

UTR-J

GROUP

P.7/8

UT753-A

UT750

MA04J

SM4802

WK21

NM440

SM411

UT752

UT763

UT232

SM135

WK09

UT756

SM471

Ⓐ

UT755

Ⓐ

UT757

NM300

UT754

UT753

UT758

SM036

SM031

UT759

UT751

SM432

WM400

WK05

WM110

SM135

UT761

UT760

SM001

UT762

UT761

SM035

SM035

SM035

SM035

SM035

SM035


SM035

SM035


SM035

UT763-A=UT753-A+UT763+UT232+NM300+SM411


C007J PARTS LIST FOR UTR-J(UTS-J) GROUP P.8/8




C007JDPARTS LIST FOR UTR-J(UTS-J) GROUP P.1/11




C007JD PARTS LIST FOR UTR-J(UTS-J) GROUP P.10/11



C007JDPARTS LIST FOR UTR-J(UTS-J) GROUP P.11/11



C007JD PARTS LIST FOR UTR-J(UTS-J) GROUP P.2/11





C007JD PARTS LIST FOR UTR-J(UTS-J) GROUP P.3/11


FOR UTR/WP/UTU

FOR UTS/UTY

A



UT226D
WP22(WP)



TO WIPER

UT763



EP107

UT534



TO UNDER
TRIMMER

B

UT103E

TO SAFETY S.W

TO SYNCHRONIZER

C

TO MAIN
POWER

TXXXXX


D

T999


TO PRESSER FOOT

E

UT230-E
FOR CL USE



UT810-A1



FOR C007JD/C858JD/S007KD

FOR H牌馬達 (HVP-20)


10/07/01

C007JD PARTS LIST FOR UTR-J(UTS-J) GROUP P.4/11


FOR UTR/WP/UTU

FOR UTS/UTY

A



UT218J



UT226D
UT226P


WP22(WP)

TO WIPER

UT763




UT534



TO UNDER TRIMMER

EP107




TO PRESSER FOOT


D

E

UT230-E
FOR CL USE



UT810-A1
UT810P-A



FOR C007JD/C858JD/S007KD

FOR H牌馬達 (HVP-70)
FOR P牌馬達

10/07/01

C007JD PARTS LIST FOR UTR-J(UTS-J) GROUP P.5/11


A

B


C

D


E




USE FOR C007J



USE FOR C007JD



C007JDPARTS LIST FOR UTR-J(UTS-J) GROUP P.6/11



C007JD PARTS LIST FOR UTR(UTS) GROUP P.7/11


A

B

C


D

E



UTK/UTS系列

UT218J-A1



C007JD PARTS LIST

FOR

UTR-J

GROUP P.8/11

UT753-A

UT750

MA04J

SM4802

WK21

NM440

SM411

UT752

UT763

UT232

SM135

WK09

UT756

SM471

UT755

UT757

NM300

UT754

UT753

UT751

SM432

WM400

WK05

WM110

SM135

UT758

SM036

SM031

UT759

SM035

UT762

UT761

UT760

SM001

UT763-A=UT753-A+UT763+UT232+NM300+SM411

C007JD PARTS LIST FOR UTR-J(UTS-J) GROUP P.9/11

